




**APEX DYNAMICS, INC.**

**PEII - SERIES**  
**PLANETARY GEARBOX**  
**NEW GENERATION**



# PEII Series

## ► Features:

- Economic**
- High efficiency**
- Low noise**
- Reduced backlash**
- Optimized Inertia moment**
- Limited temperature rise**
- Long service life**
- Flexible mounting diameters**
- Minimized size and weight**

Your motor's perfect match!!

The brand new APEX PII series. The PII series is an economic high precision planetary gearbox with excellent performance and quality. Our innovative PII series design features minimal size, light weight and high efficiency.

## ► Ordering Code

**PEII 090** – **010** – <sup>(2)</sup> / **MOTOR**

**Motor Designation:**  
**Manufacture Type And Model**

**Ratio<sup>(1)</sup>:**  
1 stage: 3, 4, 5, 7, 10  
2 stage: 15, 16, 20, 25, 30, 35, 40, 50, 70, 100


**Gear Size:**  
**PEII:** PEIIA, PEIIB, PEIIC, PEIID, PEIIE

**Ordering Example :** **PEII 090-010 / SIEMENS 1FT6 041-4AF71**  
**PEII 090-010-S1 / SIEMENS 1FT6 041-4AF71**


(1) Other ratios are available, please contact APEX.

(2) For PSII, PEII and PGII series, the output shaft with key (S2) is standard.  
For PAII series, the S1 and S2 are both available.


# Permitted Radial And Axial Loads On Output Shaft



The permitted radial and axial loads on output shaft of the gearbox depend on the design of the gearbox supporting bearings.



If radial force  $F_{2r}$  is not exerted on the center of the output shaft  $X < 1/2 \times L$  or  $X > 1/2 \times L$ , the permitted radial and axial loads can be calculated by the position load factor  $K_b$  on the above diagram.



Permitted radial load  $F_{2r}$  on center of output shaft  $X = 1/2 \times L$  for various output speeds.  
Values provided are for 20,000 hours<sup>(\*)</sup> life.

<sup>(\*)</sup> For Continuous Operation(S1), the service life reduced to 50%.

# PEII Series Specifications

PEII 050		1-stage					2-stage																			
		Ratio <sup>(1) (2)</sup>					Ratio <sup>(1) (2)</sup>																			
		3	4	5	7	10	15	16	20	25	30	35	40	50	70	100										
Nominal Output Torque T <sub>2N</sub>	Nm	4.4	6.1	5.9	5.4	5.3	4.3	5.9	5.9	6.2	4.3	5.8	5.8	6.1	5.8	5.7										
Emergency Stop Torque T <sub>2NOT</sub>	Nm	3 times T <sub>2N</sub>																								
Max. Acceleration Torque T <sub>2B</sub>	Nm	7.9	11	10.6	9.7	9.5	7.7	10.6	10.6	11.2	7.7	10.4	10.4	11	10.4	10.3										
No Load Running Torque <sup>(8)</sup>	Nm	0.05					0.05																			
Backlash <sup>(3)</sup>	arcmin	≤ 7					≤ 9																			
Torsional Rigidity	Nm/arcmin	0.9					0.9																			
Nominal Input Speed n <sub>1N</sub>	rpm	4,500																								
Max. Input Speed n <sub>1B</sub>	rpm	8,000																								
Max. Radial Load F <sub>2rB</sub> <sup>(4)</sup>	N	840																								
Max. Axial Load F <sub>2aB</sub> <sup>(4)</sup>	N	420																								
Service Life <sup>(7)</sup>	hr	20,000																								
Operating Temperature	° C	0° C ~ +90° C																								
Lubrication		Synthetic lubrication grease																								
Mounting Position		All directions																								
Running Noise <sup>(6) (8)</sup>	dB(A)	≤ 60					≤ 60																			
Efficiency η	%	≥ 97%					≥ 94%																			
Weight	kg	Ø <sup>(5)</sup> ≤ 8, 11, 14 = 0.7					Ø <sup>(5)</sup> ≤ 8, 11, 14 = 0.8																			
Moment of Inertia J <sub>1</sub>	kg.cm <sup>2</sup>	Ø <sup>(5)</sup> ≤ 8	0.11	0.10	0.10	0.10	0.10	0.10	0.10	0.10	0.10	0.10	0.10	0.10	0.10	0.10										
		Ø <sup>(5)</sup> ≤ 11	0.17	0.16	0.16	0.16	0.16	0.16	0.16	0.16	0.16	0.16	0.16	0.16	0.16	0.16										
		Ø <sup>(5)</sup> ≤ 14	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20										

(1) Ratio (i = N<sub>in</sub> / N<sub>out</sub>).

(2) Other ratios are available, please contact APEX.

(3) Backlash is measured at 2% of Nominal Output Torque T<sub>2N</sub>.

(4) Applied to the output shaft center at 100 rpm.




(5) Ø = Input shaft diameter.

(6) These values are measured at 3000 rpm without load.




(7) For continuous operation, the service life is 10000 hrs.

(8) These values are measured with ratio=10 (1-stage) and ratio=100 (2-stage) at 3000 rpm.




# PEII Series Dimension






$\varnothing^{(5)} \leq 8$



$\varnothing^{(5)} \leq 11$



$\varnothing^{(5)} \leq 14$



Shaft Detail A

Shaft Detail

- (1) This dimension refers to motor shaft diameter.
- (2) The maximum motor shaft length. For other Motor specific dimensions, please contact APEX.
- (3) Input dimensions vary according to motor flange.
- (4) Please contact APEX, if there is no proper dimension.
- (5) Ø= Input shaft diameter.

# PEII Series Specifications

PEII 070		1-stage					2-stage																			
		Ratio <sup>(1) (2)</sup>					Ratio <sup>(1) (2)</sup>																			
		3	4	5	7	10	15	16	20	25	30	35	40	50	70	100										
Nominal Output Torque T <sub>2N</sub>	Nm	15	21	19.5	18	17.7	14.5	20	20	21	14	19.3	19.2	20	19.6	18.8										
Emergency Stop Torque T <sub>2NOT</sub>	Nm	3 times T <sub>2N</sub>																								
Max. Acceleration Torque T <sub>2B</sub>	Nm	27	37.8	35.1	32.4	31.9	26.1	36	36	37.8	25.2	34.7	34.6	36	35.3	33.8										
No Load Running Torque <sup>(8)</sup>	Nm	0.1					0.1																			
Backlash <sup>(3)</sup>	arcmin	≤ 6					≤ 8																			
Torsional Rigidity	Nm/arcmin	2.2					2.2																			
Nominal Input Speed n <sub>1N</sub>	rpm	4,000																								
Max. Input Speed n <sub>1B</sub>	rpm	6,000																								
Max. Radial Load F <sub>2rB</sub> <sup>(4)</sup>	N	1,290																								
Max. Axial Load F <sub>2aB</sub> <sup>(4)</sup>	N	645																								
Service Life <sup>(7)</sup>	hr	20,000																								
Operating Temperature	° C	0° C ~ +90° C																								
Lubrication		Synthetic lubrication grease																								
Mounting Position		All directions																								
Running Noise <sup>(6) (8)</sup>	dB(A)	≤ 62					≤ 62																			
Efficiency η	%	≥ 97%					≥ 94%																			
Weight	kg	$\varnothing^{(5)} \leq 8, 11, 14 = 1.2$ $\varnothing^{(5)} \leq 19 = 1.9$					$\varnothing^{(5)} \leq 8, 11, 14 = 1.5$ $\varnothing^{(5)} \leq 19 = 2.2$																			
Moment of Inertia J <sub>1</sub>	kg.cm <sup>2</sup>	$\varnothing^{(5)} \leq 8$	0.13	0.11	0.10	0.10	0.10	0.10	0.11	0.10	0.10	0.10	0.10	0.10	0.10	0.10										
		$\varnothing^{(5)} \leq 11$	0.19	0.17	0.17	0.17	0.17	0.17	0.17	0.17	0.17	0.17	0.17	0.17	0.17	0.17										
		$\varnothing^{(5)} \leq 14$	0.25	0.23	0.22	0.22	0.22	0.22	0.23	0.22	0.22	0.22	0.22	0.22	0.22	0.22										
		$\varnothing^{(5)} \leq 19$	1.54	1.52	1.52	1.51	1.51	1.52	1.52	1.52	1.51	1.52	1.51	1.51	1.51	1.51										

(1) Ratio (i = N<sub>in</sub> / N<sub>out</sub>).

(2) Other ratios are available, please contact APEX.

(3) Backlash is measured at 2% of Nominal Output Torque T<sub>2N</sub>.

(4) Applied to the output shaft center at 100 rpm.




(5) Ø = Input shaft diameter.

(6) These values are measured at 3000 rpm without load.




(7) For continuous operation, the service life is 10000 hrs.

(8) These values are measured with ratio=10 (1-stage) and ratio=100 (2-stage) at 3000 rpm.




# PEII Series Dimension






$\varnothing^{(5)} \leq 8$






$\varnothing^{(5)} \leq 11$



$\varnothing^{(5)} \leq 14$



$\varnothing^{(5)} \leq 19$



Shaft Detail A

- (1) This dimension refers to motor shaft diameter.
- (2) The maximum motor shaft length. For other Motor specific dimensions, please contact APEX.
- (3) Input dimensions vary according to motor flange.
- (4) Please contact APEX, if there is no proper dimension.
- (5)  $\varnothing$ = Input shaft diameter.

# PEII Series Specifications

PEII 090		1-stage					2-stage																			
		Ratio <sup>(1) (2)</sup>					Ratio <sup>(1) (2)</sup>																			
		3	4	5	7	10	15	16	20	25	30	35	40	50	70	100										
Nominal Output Torque T <sub>2N</sub>	Nm	33	46	48	49	46	32	44	44	46	32	54	43	45	54	48										
Emergency Stop Torque T <sub>2NOT</sub>	Nm	3 times T <sub>2N</sub>																								
Max. Acceleration Torque T <sub>2B</sub>	Nm	59.4	82.8	86.4	88.2	82.8	57.6	79.2	79.2	82.8	57.6	97.2	77.4	81	97.2	86.4										
No Load Running Torque <sup>(8)</sup>	Nm	0.4					0.3																			
Backlash <sup>(3)</sup>	arcmin	$\leq 5$					$\leq 7$																			
Torsional Rigidity	Nm/arcmin	8					8																			
Nominal Input Speed n <sub>1N</sub>	rpm	3,600																								
Max. Input Speed n <sub>1B</sub>	rpm	6,000																								
Max. Radial Load F <sub>2rB</sub> <sup>(4)</sup>	N	1,510																								
Max. Axial Load F <sub>2aB</sub> <sup>(4)</sup>	N	755																								
Service Life <sup>(7)</sup>	hr	20,000																								
Operating Temperature	° C	0° C ~ +90° C																								
Lubrication		Synthetic lubrication grease																								
Mounting Position		All directions																								
Running Noise <sup>(6) (8)</sup>	dB(A)	$\leq 64$					$\leq 64$																			
Efficiency η	%	$\geq 97\%$					$\geq 94\%$																			
Weight	kg	$\varnothing^{(5)} \leq 14 = 2.4$ $\varnothing^{(5)} \leq 19, 24, 28 = 3.4$					$\varnothing^{(5)} \leq 14 = 3.3$ $\varnothing^{(5)} \leq 19, 24, 28 = 4.3$																			
Moment of Inertia J <sub>1</sub>	kg.cm <sup>2</sup>	$\varnothing^{(5)} \leq 14$	0.38	0.27	0.25	0.24	0.24	0.25	0.27	0.25	0.25	0.24	0.25	0.24	0.24	0.24	0.24									
		$\varnothing^{(5)} \leq 19$	1.77	1.66	1.64	1.63	1.63	1.64	1.66	1.64	1.64	1.63	1.64	1.63	1.63	1.63	1.63									
		$\varnothing^{(5)} \leq 24$	2.33	2.22	2.20	2.19	2.19	2.20	2.22	2.20	2.20	2.19	2.20	2.19	2.19	2.19	2.19									
		$\varnothing^{(5)} \leq 28$	2.86	2.75	2.73	2.72	2.71	2.73	2.75	2.73	2.73	2.71	2.73	2.71	2.71	2.71	2.71									

(1) Ratio ( $i = N_{in} / N_{out}$ ).

(2) Other ratios are available, please contact APEX.

(3) Backlash is measured at 2% of Nominal Output Torque T<sub>2N</sub>.

(4) Applied to the output shaft center at 100 rpm.


(5)  $\varnothing$  = Input shaft diameter.

(6) These values are measured at 3000 rpm without load.

(7) For continuous operation, the service life is 10000 hrs.

(8) These values are measured with ratio=10 (1-stage) and ratio=100 (2-stage) at 3000 rpm.

# PEII Series Dimension



- (1) This dimension refers to motor shaft diameter.
- (2) The maximum motor shaft length. For other Motor specific dimensions, please contact APEX.
- (3) Input dimensions vary according to motor flange.
- (4) Please contact APEX, if there is no proper dimension.
- (5)  $\emptyset$ = Input shaft diameter.

**Shaft Detail**

# PEII Series Specifications

PEII 120		1-stage					2-stage																			
		Ratio <sup>(1) (2)</sup>					Ratio <sup>(1) (2)</sup>																			
		3	4	5	7	10	15	16	20	25	30	35	40	50	70	100										
Nominal Output Torque T <sub>2N</sub>	Nm	51	72	76	91	74	50	70	70	73	50	88	68	71	86	77										
Emergency Stop Torque T <sub>2NOT</sub>	Nm	3 times T <sub>2N</sub>																								
Max. Acceleration Torque T <sub>2B</sub>	Nm	91.8	130	137	164	133	90	126	126	131	90	158	122	128	155	139										
No Load Running Torque <sup>(8)</sup>	Nm	0.8					0.4																			
Backlash <sup>(3)</sup>	arcmin	$\leq 5$					$\leq 7$																			
Torsional Rigidity	Nm/arcmin	12					12																			
Nominal Input Speed n <sub>1N</sub>	rpm	3,600																								
Max. Input Speed n <sub>1B</sub>	rpm	4,800																								
Max. Radial Load F <sub>2rB</sub> <sup>(4)</sup>	N	3,780																								
Max. Axial Load F <sub>2aB</sub> <sup>(4)</sup>	N	1,890																								
Service Life <sup>(7)</sup>	hr	20,000																								
Operating Temperature	° C	0° C ~ +90° C																								
Lubrication		Synthetic lubrication grease																								
Mounting Position		All directions																								
Running Noise <sup>(6) (8)</sup>	dB(A)	$\leq 66$					$\leq 66$																			
Efficiency η	%	$\geq 97\%$					$\geq 94\%$																			
Weight	kg	$\varnothing^{(5)} \leq 19, 24, 28 = 6.5$ $\varnothing^{(5)} \leq 32, 35 = 8$ $\varnothing^{(5)} \leq 38 = 11.9$					$\varnothing^{(5)} \leq 19, 24, 28 = 8.5$ $\varnothing^{(5)} \leq 32, 35 = 10.1$ $\varnothing^{(5)} \leq 38 = 14$																			
Moment of Inertia J <sub>1</sub>	kg.cm <sup>2</sup>	$\varnothing^{(5)} \leq 19$	2.41	1.96	1.88	1.84	1.83	1.88	1.96	1.88	1.88	1.83	1.88	1.83	1.83	1.83										
		$\varnothing^{(5)} \leq 24$	3.11	2.66	2.57	2.54	2.53	2.57	2.66	2.57	2.57	2.53	2.57	2.53	2.53	2.53										
		$\varnothing^{(5)} \leq 28$	3.40	2.96	2.87	2.84	2.83	2.87	2.96	2.87	2.87	2.83	2.87	2.83	2.83	2.83										
		$\varnothing^{(5)} \leq 32$	8.00	7.55	7.47	7.43	7.42	7.47	7.55	7.47	7.47	7.42	7.47	7.42	7.42	7.42										
		$\varnothing^{(5)} \leq 35$	10.97	10.52	10.44	10.40	10.39	10.44	10.52	10.44	10.44	10.39	10.44	10.39	10.39	10.39										
		$\varnothing^{(5)} \leq 38$	14.18	13.73	13.65	13.61	13.60	13.65	13.73	13.65	13.65	13.60	13.65	13.60	13.60	13.60										

(1) Ratio (i = N<sub>in</sub> / N<sub>out</sub>).

(2) Other ratios are available, please contact APEX.

(3) Backlash is measured at 2% of Nominal Output Torque T<sub>2N</sub>.

(4) Applied to the output shaft center at 100 rpm.




(5) Ø = Input shaft diameter.

(6) These values are measured at 3000 rpm without load.




(7) For continuous operation, the service life is 10000 hrs.

(8) These values are measured with ratio=10 (1-stage) and ratio=100 (2-stage) at 3000 rpm.




# PEII Series Dimension



$\emptyset^{(5)} \leq 19$



$\emptyset^{(5)} \leq 24$






Shaft Detail A




- (1) This dimension refers to motor shaft diameter.
- (2) The maximum motor shaft length. For other Motor specific dimensions, please contact APEX.
- (3) Input dimensions vary according to motor flange.
- (4) Please contact APEX, if there is no proper dimension.
- (5)  $\emptyset$ = Input shaft diameter.

# PEII Series Dimension




►  $\varnothing^{(5)} \leq 28$



►  $\varnothing^{(5)} \leq 32$











► Shaft Detail



Shaft Detail A

- (1) This dimension refers to motor shaft diameter.
- (2) The maximum motor shaft length. For other Motor specific dimensions, please contact APEX.
- (3) Input dimensions vary according to motor flange.
- (4) Please contact APEX, if there is no proper dimension.
- (5)  $\varnothing$ = Input shaft diameter.

# PEII Series Dimension



Shaft Detail

- (1) This dimension refers to motor shaft diameter.
- (2) The maximum motor shaft length. For other Motor specific dimensions, please contact APEX.
- (3) Input dimensions vary according to motor flange.
- (4) Please contact APEX, if there is no proper dimension.
- (5) Ø= Input shaft diameter.

# PEII Series Specifications

PEII 155		1-stage					2-stage																			
		Ratio <sup>(1) (2)</sup>					Ratio <sup>(1) (2)</sup>																			
		3	4	5	7	10	15	16	20	25	30	35	40	50	70	100										
Nominal Output Torque T <sub>2N</sub>	Nm	102	143	150	178	123	101	140	140	145	99	174	136	140	171	128										
Emergency Stop Torque T <sub>2NOT</sub>	Nm	3 times T <sub>2N</sub>																								
Max. Acceleration Torque T <sub>2B</sub>	Nm	184	257	270	320	221	182	252	252	261	178	313	245	252	308	230										
No Load Running Torque <sup>(8)</sup>	Nm	2.5					0.8																			
Backlash <sup>(3)</sup>	arcmin	$\leq 5$					$\leq 7$																			
Torsional Rigidity	Nm/arcmin	16					16																			
Nominal Input Speed n <sub>1N</sub>	rpm	2,500																								
Max. Input Speed n <sub>1B</sub>	rpm	3,600																								
Max. Radial Load F <sub>2rB</sub> <sup>(4)</sup>	N	4,600																								
Max. Axial Load F <sub>2aB</sub> <sup>(4)</sup>	N	2,300																								
Service Life <sup>(7)</sup>	hr	20,000																								
Operating Temperature	° C	0° C ~ +90° C																								
Lubrication		Synthetic lubrication grease																								
Mounting Position		All directions																								
Running Noise <sup>(6) (8)</sup>	dB(A)	$\leq 68$					$\leq 68$																			
Efficiency η	%	$\geq 97\%$					$\geq 94\%$																			
Weight	kg	$\varnothing^{(5)} \leq 24, 28 = 11.2$ $\varnothing^{(5)} \leq 32, 35 = 12.8$ $\varnothing^{(5)} \leq 38, 42 = 16.8$					$\varnothing^{(5)} \leq 19, 24, 28 = 15.2$ $\varnothing^{(5)} \leq 32, 35 = 16.8$ $\varnothing^{(5)} \leq 38 = 20.7$																			
Moment of Inertia J <sub>1</sub>	kg.cm <sup>2</sup>	$\varnothing^{(5)} \leq 19$	-	-	-	-	2.18	2.50	2.18	2.18	2.00	2.18	2.00	2.00	2.00	2.00										
		$\varnothing^{(5)} \leq 24$	4.80	3.06	2.74	2.60	2.56	2.74	3.06	2.74	2.74	2.56	2.74	2.56	2.56	2.56										
		$\varnothing^{(5)} \leq 28$	5.22	3.49	3.16	3.02	2.99	3.16	3.49	3.16	3.16	2.99	3.16	2.99	2.99	2.99										
		$\varnothing^{(5)} \leq 32$	10.74	9.00	8.68	8.53	8.50	8.68	9.00	8.68	8.68	8.50	8.68	8.50	8.50	8.50										
		$\varnothing^{(5)} \leq 35$	14.14	12.40	12.08	11.93	11.90	12.08	12.40	12.08	12.08	11.90	12.08	11.90	11.90	11.90										
		$\varnothing^{(7)} \leq 38$	17.20	15.46	15.14	15.00	14.96	15.14	15.46	15.14	15.14	14.96	15.14	14.96	14.96	14.96										
		$\varnothing^{(7)} \leq 42$	25.85	24.12	23.79	23.65	23.62	-	-	-	-	-	-	-	-	-										

(1) Ratio ( $i = N_{in} / N_{out}$ ).

(2) Other ratios are available, please contact APEX.

(3) Backlash is measured at 2% of Nominal Output Torque T<sub>2N</sub>.

(4) Applied to the output shaft center at 100 rpm.




(5)  $\varnothing$  = Input shaft diameter.

(6) These values are measured at 3000 rpm without load.




(7) For continuous operation, the service life is 10000 hrs.

(8) These values are measured with ratio=10 (1-stage) and ratio=100 (2-stage) at 3000 rpm.




# PEII Series Dimension






$\varnothing^{(5)} \leq 19$



$\varnothing^{(5)} \leq 24$



$\varnothing^{(5)} \leq 28$






Shaft Detail A

Shaft Detail




- (1) This dimension refers to motor shaft diameter.
- (2) The maximum motor shaft length. For other Motor specific dimensions, please contact APEX.
- (3) Input dimensions vary according to motor flange.
- (4) Please contact APEX, if there is no proper dimension.
- (5)  $\varnothing$ = Input shaft diameter.

# PEII Series Dimension




►  $\varnothing^{(5)} \leq 32$



►  $\varnothing^{(5)} \leq 35$






► Shaft Detail






Shaft Detail A

- (1) This dimension refers to motor shaft diameter.
- (2) The maximum motor shaft length. For other Motor specific dimensions, please contact APEX.
- (3) Input dimensions vary according to motor flange.
- (4) Please contact APEX, if there is no proper dimension.
- (5)  $\varnothing$ = Input shaft diameter.



# PEII Series Dimension



Ø<sup>(5)</sup>≤38



Ø<sup>(5)</sup>≤42





Shaft Detail A

Shaft Detail

- (1) This dimension refers to motor shaft diameter.
- (2) The maximum motor shaft length. For other Motor specific dimensions, please contact APEX.
- (3) Input dimensions vary according to motor flange.
- (4) Please contact APEX, if there is no proper dimension.
- (5) Ø= Input shaft diameter.

# Selection of the optimum gearbox



$$1. ED = \frac{t_a + t_c + t_d}{t_{cycle}} \times 100\%, t_{work} = t_a + t_c + t_d$$

Index : a. Acceleration, c. Constant, d. Deceleration, p. Pause (Eq.1)

$$2. i \approx \frac{n_m}{n_{work}}$$

$n_m$  Output Speed of the Motor

$n_{work}$  Working Speed (Eq.2)

$$3. T_{2m} = \sqrt[3]{\frac{n_{2a} \times t_a \times T_{2a}^3 + n_{2c} \times t_c \times T_{2c}^3 + n_{2d} \times t_d \times T_{2d}^3}{n_{2a} \times t_a + n_{2c} \times t_c + n_{2d} \times t_d}}$$

$$4. T_{2max} = T_{mB} \times i \times K_s \times \eta$$

where  $K_s$  is

$K_s$	No. of Cycles / hr
1.0	0 ~ 1,000
1.1	1,000 ~ 1,500
1.3	1,500 ~ 2,000
1.6	2,000 ~ 3,000
1.8	3,000 ~ 5,000

$T_{mB}$  Max. Output Torque of the Motor

$\eta$  Efficency of the Gearbox (Eq.4)

$$5. n_{2a} = n_{2d} = \frac{1}{2} \times n_{2c}$$

$$n_{2m} = \frac{n_{2a} \times t_a + n_{2c} \times t_c + n_{2d} \times t_d}{t_a + t_c + t_d}$$

$$n_{2N} = \frac{n_{1N}}{i}$$

$$6. F_{2rm} = \sqrt[3]{\frac{n_{2a} \times t_a \times F_{2ra}^3 + n_{2c} \times t_c \times F_{2rc}^3 + n_{2d} \times t_d \times F_{2rd}^3}{n_{2a} \times t_a + n_{2c} \times t_c + n_{2d} \times t_d}}$$

$$F_{2am} = \sqrt[3]{\frac{n_{2a} \times t_a \times F_{2aa}^3 + n_{2c} \times t_c \times F_{2ac}^3 + n_{2d} \times t_d \times F_{2ad}^3}{n_{2a} \times t_a + n_{2c} \times t_c + n_{2d} \times t_d}}$$

## Recommended (for S5 Cycle Operation)

The general design is given for

$$\frac{J_L}{i^2} \leq 4 \times J_m$$

The optimal design is given for

$J_L$  Load Inertia

$J_m$  Motor Inertia

# Glossary

Emergency Stop Torque $T_{2\text{NOT}}$	Nm	The Emergency Stop Torque is the maximum permitted torque at the output of gearbox. This may happen only occasionally and may not exceed 1000 times during the whole service life.
Max. Acceleration Torque $T_{2B}$	Nm	Under the Cyclic Operation (S5), the Max. Acceleration Torque is the maximum torque which can be transmitted only briefly to the output of gearbox up to 1000 cycles/hr.
No Load Running Torque	Nm	The No Load Running Torque is the min. torque to overcome the internal friction of a gearbox without loading*.
Nominal Input Speed $n_{1N}$	rpm	The Nominal Input Speed is the permitted input speed of gearbox by the Continuous Operation (S1) while the housing temperature does not exceed 90°C. This value is measured at environment temperature 25°C.
Max. Input Speed $n_{1B}$	rpm	The Max. Input Speed is the max. permitted input speed of gearbox by the Cyclic operation (S5). This value is measured at environment temperature 25°C and serves as the absolute limit of the gearbox.
Backlash	arcmin	The Backlash is the maximum angular measurement between two teeth of gears when the transverse operation occurs (refer to Diagram 1). The arcmin is the measurement unit for the backlash. One arcmin equals 1/ 60 degree, symbolized as 1'.  
Torsional Rigidity	Nm/arcmin	Torsional Rigidity is the quotient ( $\Delta T / \Delta \phi$ ) between the applied torque and resulting torsion angle. This value indicates how many torque needed on gearbox to rotate the output shaft for 1 arcmin. The Torsional Rigidity can be determined by Hysteresis Curve.  Hysteresis Curve When the input shaft is locked, increase torque at the output slowly up to $T_{2B}$ in both directions and then release the torque gradually. According to the measured torque and torsion angle, a closed curve will be acquired as Diagram 2.  
Efficiency $\eta$	%	The transmission efficiency of the gears inside a gearbox (without friction).
Operating Temperature	°C	The Operating Temperature indicates the temperature of gearbox housing.
Lubrication		APEX uses synthetic lubrication grease. There are other grease available, please contact APEX.
Running Noise	dB(A)	The Running Noise is measured depends on gearbox size, the ratio and the speed*. Higher speed induces usually higher noise level, while higher ratio induces lower noise level.
Moment of Inertia $J_1$	kg.cm <sup>2</sup>	The Moment of Inertia $J_1$ is a measurement of the effort applied to an object to maintain its momentary condition at rest or rotating.
Breakaway Torque	Nm	The Breakaway Torque is the minimum torque to start the rotation from the input side of gearbox. A smaller size or a higher ratio gearbox requests less Breakaway Torque.
Back Driving Torque	Nm	The Back Driving Torque is the minimum torque to start the rotation from the output side of gearbox. A larger size or a higher ratio gearbox requests greater Back Driving Torque.

\* This value is measured at environment temperature 25°C and the input speed 3000 rpm. If the Nominal Input Speed  $n_{1N}$  of gearbox is over 3000 rpm, this value is measured by that specific Nominal Input Speed.

© 2013 by APEX DYNAMICS, INC.

In terms of the continuously development of products, the modifications and copy rights of all technical specifications, illustrations and drawings in this catalog are reserved by APEX DYNAMICS, INC. For the newest data and information, please visit APEX website: [www.apexdynamics.com](http://www.apexdynamics.com).



## APEX DYNAMICS, INC.

No. 10, Keyuan 3rd Road, Situn District, Taichung City 407, Taiwan R.O.C

TEL: 886-4-24650219 / FAX: 886-4-24650118

E-Mail: sales@apexdyna.com Website: www.apexdyna.com

APEX-2013-04-PII SERIES-1.0E-2.0V

